

### bizhub C3110

### **Quick Start Guide**

### INDEX



- 2. About Manuals
- 3. Overview of This Machine
- 4. Loading Paper
- 5. Initial Settings of This Machine
- 6. Basic Usage
- 7. Index

### **Table of contents**

### 1 Introduction

1.1	Environmental Information ENERGY STAR <sup>®</sup>	1-2
	What is an ENERGY STAR® Product?	
	Environmental benefits of power management	
	Recycled Paper	
	Duplex printing	
1.2	Safety information	
	Warning and precaution symbols  These are some of major exemplary graphical symbols	
	Power source connection>	
	<installation></installation>	
	<using product="" the=""></using>	
	<consumables></consumables>	
1.3	Regulation notices	
1.0	GS Certification	
	CE Marking (Declaration of Conformity) for users of the European Union (EU)	
	USER INSTRUCTIONS FCC PART 15 - RADIO FREQUENCY DEVICES (for U.S.A. users)	
	INTERFERENCE-CAUSING EQUIPMENT STANDARD (ICES-003 ISSUE 5) (for Canada users)	
	Electromagnetic Interference	
	Laser Safety	
	Internal Laser Radiation	
	CDRH regulations	
	For European usersFor Denmark users	
	For Finland, Sweden users	
	For Norway users	
	Laser safety label	
	Ozone Release	
	Dégagement d'ozone	1-12
	Acoustic noise (for European users only)	1-12
	Notification for US only	
	Notification for California Customers	
	For EU member states only	
	For EU member states only	
	USB Host	
1.4	Regulatory notices for telecommunication terminal equipment	
1.4.1	Special Notice to User	
	For Canada	
	For U.S.A	
	For New Zealand	
	For Europe	
1.5	Regulatory notices for wireless products	
	Modular component notice	
	Exposure to radio frequency radiation	
	Industry Canada (Canada)	
	Industry Canada (Canada)	
	Notice to users in the European Union	
1.6	·	
	Caution notations and labels	
1.7	Space requirementsFront view	
	Right view (with optional devices installed)	
4.0	,	
1.8	Operation precautions	
	Operating environment	
	Storage of copies	
		1

		Data stored in this machine	
	1.9	Precautions for Carrying the Machine  Legal restrictions on reproduction	
	1.0	Logui restrictions on reproduction	······································
2	About	t Manuals	
	2.1	About Manuals	2-2
	2.2	User's Guides	
		Booklet manuals	
		User's guides included in User's Guide CD-ROM	2-3
	2.3	User's Guide CD-ROM	2-4
	2.3.1	Operating environment	2-4
	2.3.2	Displaying the top page	
		For Windows	
		For Mac OS	
	2.4	Notations and symbols used in this manual  Procedural instruction	
		Symbols used in this manual	
		Product and key names	
		Notations of application names	2-5
3	Overv	riew of This Machine	
	3.1	About This Machine	
	3.1.1	Name of each part	
		Front side Rear side	
	0.4.0		
	3.1.2	Option configuration	
	3.2	About Power Supply	
	3.2.1	Turning the Power Switch ON or OFF	
	3.2.2	Switching to Power Save mode	
	3.3	Control Panel	
	3.4	Screen Layout	
	3.4.1	Main screen	
		Scan mode	
		Fax mode	3-10
	3.4.2	Help screen	3-10
	3.5	Entering Characters	3-11
		Changing the entry mode	
		Available characters	3-11
4	Loadi	ng Paper	
	4.1	Paper	4-2
	4.1.1	Checking the available paper types	
	4.1.2	Checking the available paper sizes	
	4.1.3	Precautions for correct operations	
		Unavailable paper	4-4
		Storing paper	
	4.2	Loading paper into the Manual Feed Tray	
	4.3	Loading paper into Tray 1	4-7
5	Initial	Settings of This Machine	
	5.1	Preparation for network connection (for administrators)	5-2
		Checking a LAN cable for connection	5-2
		Assigning an IP address	5-2

5.2	Preparation for fax (for administrators)	5-3
	Checking the modular cable connection	
	<u> </u>	
5.3	Hard disk (HDD) setting (for administrators)	
Basic	Usage	
		6.0
	,	
•		
0.1.2		
	Checking the network settings	
	Installing the printer driver	6-3
6.1.3	Preparation for printing (USB connection)	6-4
	Server 2012/Server 2012 R2)	6-4
	Installing the printer driver	6-5
6.1.4	Initial settings of the printer driver	6-7
6.1.5	How to print	6-8
6.2	Using the scan function	6-9
6.2.1	Available operations in the scan function	6-9
6.2.2	How to scan	6-10
6.3	Using Fax Functions	6-11
6.3.1	Fax functions	6-11
6.3.2	How to Send	6-11
6.3.3	Introduction of fax transmission function	6-12
6.3.4	Introduction of fax receiving function	6-12
6.4	Using the copy function	6-13
6.4.1	How to copy	6-13
6.4.2	Introduction of copy function	6-14
6.5	Printing a file stored in USB memory	6-15
	Supported USB memory devices	
	How to print	6-15
6.6	Address Registration	
	Address book	
	Registering E-mail addresses	
	5.3  Basic 6.1 6.1.1 6.1.2  6.1.3  6.1.4 6.1.5 6.2 6.2.1 6.2.2 6.3 6.3.1 6.3.2 6.3.3 6.3.4 6.4 6.4.1 6.4.2 6.5	Checking the modular cable connection Specifying the type of telephone line Preparing to use the machine in a Private Branch Exchange (PBX) environment Selecting a receiving method. Registering the sender information Setting the date and time for the machine.  5.3 Hard disk (HDD) setting (for administrators)  Basic Usage 6.1 Using the print function (Windows environment) 6.1.1 Printer driver 6.1.2 Preparation for printing (network connection) Checking a LAN cable for connection Checking the network settings Installing the printer driver 6.1.3 Preparation for printing (USB connection) Changing the installation settings (Windows 7/8/8.1/Server 2008 R2/ Server 2012/Server 2012 R2) Installing the printer driver 6.1.4 Initial settings of the printer driver 6.1.5 How to print 6.2 Using the scan function 6.2.1 Available operations in the scan function 6.2.2 How to scan 6.3.1 Fax functions 6.3.3 Introduction of fax transmission function 6.3.4 Introduction of fax receiving function 6.4.1 How to copy 6.4.2 Introduction of copy function 6.5 Printing a file stored in USB memory Supported USB memory Supported USB memory Address Book How to print 6.6 Address Registration Address Book Registering a fax destination

### 7 Index

Contents-4 [Quick Start Guide]



### 1 Introduction

This [Quick Start Guide] uses illustrations to describe operating procedures for the most commonly used functions in an easy-to-understand way.

Start by using this manual to become proficient with the useful functions that this machine offers.

For details on the various functions, refer to the User's Guides on the User's Guide CD included with this machine.

In order to operate the machine safely and properly, be sure to read the safety information on page 1-4 of this manual before use.

In addition, this manual contains the following information. Be sure to read the manual before using the machine.

- Items that must be observed to use the machine safely
- Information regarding product safety
- Precautions when using the machine

The illustrations and screens used in this manual may appear slightly different from views of the actual equipment and screens.

### 1.1 Environmental Information

### **ENERGY STAR®**



As an ENERGY STAR® Partner, this machine meets the ENERGY STAR® Guidelines for energy efficiency.

### What is an ENERGY STAR® Product?

An ENERGY STAR<sup>®</sup> product has a special feature that allows it to automatically switch to a "low-power mode" after a period of inactivity. An ENERGY STAR<sup>®</sup> product uses energy more efficiently, saves you money on utility bills and helps protect the environment.

### **Environmental benefits of power management**

Electricity consumption of a device depends on both its properties and the way of using the device.

Suitable power management setting offers you resource saving usage way. By setting the time to go into power saving modes (e.g. sleep mode) shorter (or optimal), electricity consumption can be reduced.

### **Recycled Paper**

This product can print on recycled paper and environmental stewardship initiatives certified paper which complies with European standard EN 12281 as well as virgin paper. In addition it can print on lighter paper, 64g/m² for example. Using such light paper contributes to resources-saving.

1-2 [Quick Start Guide]

Introduction

### **Duplex printing**

With a product which has a duplex unit, you can print on both sides of paper automatically.

Using this function leads to reducing consumption of natural resources and your cost.

Attached printer driver provides this duplex printing function as initial setting in your computer (The setting can be changed after installation manually).

### 1.2 Safety information

This section contains detailed instructions on the operation and maintenance of this machine. To achieve optimum utility of this device, all operators should carefully read and follow the instructions in this manual.

Please read the following section before connecting the machine to the supply. It contains important information related to user safety and preventing equipment problems.

Make sure that you observe all of the precautions that appear in different sections of this manual.

KMI Ver.02 OE

### Reference

Some parts of the contents of this section may not correspond with the purchased product.

### Warning and precaution symbols

Be sure to observe the safety precautions.

• This manual contains the instructions that should be strictly observed at all times to prevent injury to yourself and other persons as well as damage to property.

Injuries and damage that might be caused by using the product improperly are classified according to the following symbols.

Pictorial indication	Description
<b>∴WARNING</b>	Improper handling can cause serious injury or death.
<b>⚠CAUTION</b>	Improper handling can cause minor injury or damage to houses and property.

### These are some of major exemplary graphical symbols.

Graphic symbols			Descriptions	Graphic symbols	Descriptions
$\Diamond$	General prohibition		Do not disassemble		Do not touch
0	General instruction	•	Ground/Earth	<b>8</b> - <b>C</b>	Unplug from outlet
<u>^</u>	General precaution		High temperature	A	Electrical shock hazard

### <Power source connection>



Do not use any power cord other than the one supplied in the package or attached on the products. If a power cord is not supplied, use only the power cord and plug that are specified in the user documentation. Failure to use this cord could result in a fire or electrical shock. If the power cord supplied in the package cannot be used in the country where this product was sold, use a power cord that meets the following conditions or contact your Technical Representative.



- The power cord has voltage and current rating appropriate for the rating plate on this machine.
- The power cord meets regulatory requirements for the area.
- The power cord is provided with grounding pin/terminal.

1-4 [Quick Start Guide]

Do not use the power cord to other products. Failure to do that could result in a fire or electrical shock.	$\Diamond$
Do not scratch, abrade, place a heavy object on, heat, twist, bend, step on, pull on, or damage the power cord. Use of a damaged power cord (exposed core wire, broken wire, etc.) could result in a fire or breakdown. Should any of these conditions be found, immediately turn OFF the power switch, unplug the power cord from the power outlet, and then call your authorized service representative.	$\Diamond$
Do not use the power source voltage other than being specified on the machine. Failure to do that could result in a fire or electrical shock.	$\Diamond$
Do not use a multiple outlet adapter to connect any other appliances or machines. Use of a power outlet for more than the marked current value could result in a fire or electrical shock.	
Do not use an extension cord. Use of an extension cord could cause a fire or electric shock. If the power cord furnished with the product is not long enough to be plugged into a wall outlet, contact your Technical Representative.	
Do not unplug and plug in the power cord with a wet hand, as an electrical shock could result.	
Plug the power cord all the way into the power outlet. Failure to do this could result in a fire or electrical shock.	0
Make sure to ground this product. (Connect the power cord to an electrical outlet that is equipped with a grounding terminal.) Failure to do so and an unlikely event of leakage could result in a fire or electrical shock.	
The outlet must be near the equipment and easily accessible. Otherwise	

## The outlet must be near the equipment and easily accessible. Otherwise you can not pull out the power plug when an emergency occurs. Do not place any objects around the power plug, as the power plug may be difficult to pull out when an emergency occurs. Do not tug the power cord when unplugging. Pulling on the power cord could damage the cord, resulting in a fire or electrical shock. Remove the power plug from the outlet more than one time a year and clean the area between the plug terminals. Dust that accumulates between the plug terminals may cause a fire.

### <Installation>

# Keep this bag away from babies and children. Do not use in cribs, beds, carriages, or playpens. The thin film may cling to nose and mouth and prevent breathing. This bag is not a toy. Do not place a flower vase or other container that contains water, or metal clips or other small metallic objects on this product. Spilled water or metallic objects dropped inside the product could result in a fire, electrical shock, or breakdown. Should a piece of metal, water, or any other similar foreign matter get inside the product, immediately turn OFF the power switch, unplug the power cord from the power outlet, and then call your Technical Representative or your authorized service representative. Make sure that the power cord is placed on a site in which no person would step on or trip over it. Stepping on or tripping over the power cord could heat the power cord, resulting in a fire or electric shock.

<b>∴</b> CAUTION	
<if fixing="" instructed="" legs="" to="" use=""> When the product has been installed, fix the product using the fixing legs. Not using the fixing legs could cause the product to move or topple over.</if>	0
Do not place the product in a dusty place, or a site exposed to soot or steam, near a kitchen table, bath, or a humidifier. A fire, electrical shock, or breakdown could result.	$\Diamond$
Do not place this product on an unstable or tilted bench, or in a location subject to a lot of vibration and shock. It could drop or fall, causing personal injury or mechanical breakdown.	$\Diamond$
Do not let any object plug the ventilation holes of this product. Heat could accumulate inside the product, resulting in a fire or malfunction.	$\Diamond$
Whenever moving this product, be sure to disconnect the power cord and other cables. Failure to do this could damage the cord or cable, resulting in a fire, electrical shock, or breakdown.	
When moving this product, always hold it at the locations specified in the User's Guide or other documents. If the unit is moved while held at locations other than those specified, it may fall, causing severe personal injury.	0

1-6 [Quick Start Guide]

1.2

Introduction

### <Using the product>

<u>^</u> WARNING	
Do not modify this product, as a fire, electrical shock, or breakdown could result. If the product employs a laser, the laser beam source could cause blindness.	
Do not attempt to remove the covers and panels which have been fixed to the product. Some products have a high-voltage part or a laser beam source inside that could cause an electrical shock or blindness.	
Do not keep using this product, if this product becomes inordinately hot or emits smoke, or unusual odor or noise. Immediately turn OFF the power switch, unplug the power cord from the power outlet, and then call your Technical Representative or your authorized service representative. If you keep on using it as is, a fire or electrical shock could result.	
Do not keep using this product, if this product has been dropped or its cover damaged. Immediately turn OFF the power switch, unplug the power cord from the power outlet, and then call your Technical Representative or your authorized service representative. If you keep on using it as is, a fire or electrical shock could result.	
Do not use flammable sprays, liquids, or gases inside or near this machine. Do not clean the inside of this machine using a flammable gas duster. A fire or explosion could result.	
<if (ih)="" (limited="" 100="" 13.56="" 20.05="" an="" being="" communication="" electromagnetic="" for="" heating="" in="" induction="" inside-the-machine="" is="" khz="" khz)="" mhz)="" module="" only="" or="" proximity="" rfid="" technology="" to="" use="" used=""> This machine generates a weak magnetic field. If you experience any unusual symptoms with your implantable medical equipment (cardiac pacemaker, etc.) while near the machine, move away from the machine and see a doctor immediately. Please call your Technical Representative or your authorized service representative if you do not understand the purchased product corresponds or not.</if>	0
<if a="" being="" card="" ic="" is="" non-contact="" reader="" used=""> If you use an implantable medical equipment (cardiac pacemaker, etc.), do not bring the IC card reader close from the implant within 12 cm at all times. The radio waves may affect implantable medical equipment (cardiac pacemaker, etc.) operations.</if>	$\Diamond$

<b>∴</b> CAUTION	
Using this product in a poorly ventilated room for a long time or producing a large volume of copies or prints may cause the odor of exhaust air from the machine. Ventilate the room well.	0
The inside of this product has areas subject to high temperature, which may cause burns.  When checking the inside of the unit for malfunctions such as a paper misfeed, do not touch the locations (around the fusing unit, etc.) which are indicated by a "Caution HOT" caution label. A burn could result.	
Unplug the product when you will not use the product for long periods of time.	8=5

1-7 [Quick Start Guide]

## When using the machine, do not look at the light of the lamp for a prolonged time. Eyestrain could result. Do not use stapled paper, conductive paper (such as silver paper or carbon paper) or treated heat-sensitive/inkjet paper, otherwise a fire may result.

### <Consumables>

### **MARNING**

Do not throw toner or a container that contains toner (e.g., toner cartridge and developing unit) into an open flame. The hot toner may scatter and cause burns or other damage.



<b>∴CAUTION</b>	
Do not leave toner-related parts (e.g., toner cartridge and developing unit) within easy reach of children. Licking any of these parts or ingesting toner could damage your health.	$\Diamond$
Do not store toner-related parts (e.g., toner cartridge and developing unit) near devices susceptible to magnetism, such as precision equipment and data storage devices, otherwise they may malfunction. They could cause these products to malfunction.	$\Diamond$
Do not force open the toner-related parts (e.g., toner cartridge and developing unit). If toner tumbles from the toner bottle, take utmost care to avoid inhaling it or even getting skin contact.	$\Diamond$
If toner lands on your skin or clothing, wash thoroughly with soap and water.	0
If you inhale toner, move to a place with fresh air and gargle with a lot of water repeatedly. Should you get symptoms such as coughing, seek medical advice.	0
If you get toner into your eyes, immediately rinse them with running water for over 15 minutes. Seek medical advice if irritation persists.	0
If you swallow toner, rinse out your mouth and drink a few glasses of water. Seek medical advice if necessary.	0
Never touch the electrical contacts of the units (e.g., toner cartridge and developing unit), as an electrostatic discharge may damage the product.	
Before handling, see the user documentation for the safety information.	[]i
<if fusing="" instructed="" replace="" the="" to="" unit=""> The fusing section is extremely hot. Before replacing the fusing unit, be sure to open doors and covers of the machine. Then, leave the machine to stand idle for a specified period of time and make sure that the fusing</if>	
section has cooled down to room temperature. Failure to follow these instructions could result in a burn.	Omin.

1-8 [Quick Start Guide]

1.3

### 1.3 Regulation notices

### **GS Certification**

This product is GS-certified for the KONICA MINOLTA branded model bizhub C3110.

The equipment is not intended for used at a video workstation in compliance BildscharbV.

### CE Marking (Declaration of Conformity) for users of the European Union (EU)

This product complies with the following EU directives: 2004/108/EC, 2006/95/EC, 2009/125/EC

This declaration is valid for the areas of the European Union (EU) or EFTA only.

This device must be used with a shielded interface cable.

The use of non-shielded interface cables is likely to result in interference with radio communications and is prohibited under 2004/108/EC rules.

### USER INSTRUCTIONS FCC PART 15 - RADIO FREQUENCY DEVICES (for U.S.A. users)

### **FCC: Declaration of Conformity**

Product Type	Multi Function Peripherals
Product Name	bizhub C3110
Options	PF-P14, MK-P04, FK-512, HD-P06, AU-201

This device complies with Part 15 of the FCC Rules

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

### NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **♠WARNING**

- The design and production of this unit conform to FCC regulations, and any changes or modifications
  must be registered with the FCC and are subject to FCC control. Any changes made by the purchaser
  or user without first contacting the manufacturer will be subject to penalty under FCC regulations.
- This device must be used with a shielded interface cable.
- The use of non-shielded cables is likely to result in interference with radio communications and is prohibited under FCC rules.

### INTERFERENCE-CAUSING EQUIPMENT STANDARD (ICES-003 ISSUE 5) (for Canada users)

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This device must be used with a shielded interface cable.

The use of non-shielded cables is likely to result in interference with radio communications and is prohibited under ICES-003.

### **Electromagnetic Interference**

This product must be used with a shielded interface cable.

The use of non-shield cables is likely to result in interference with radio communications and is prohibited under CISPR 22 and local rules.

### **Laser Safety**

This product employs a Class 3B laser diode having maximum power of 22 mW and wavelength of 770-800 nm

This product is certified as a Class 1 laser product per IEC 60825-1: 2007. Since the laser beam is concealed by protective housings, the product does not emit hazardous laser radiation as long as the product is operated according to the instructions in this manual.

### **Internal Laser Radiation**

Maximum average radiation power: 13.6 µW at the laser aperture of the print head unit.


Wavelength: 770-800 nm

This product employs a Class 3B laser diode that emits an invisible laser beam.

The laser diode and the scanning polygon mirror are incorporated in the print head unit.

The print head unit is NOT A FIELD SERVICE ITEM:

Therefore, the print head unit should not be opened under any circumstances.



1-10 [Quick Start Guide]

1.3

Introduction

### **CDRH** regulations

This machine is certified as a Class 1 Laser product under Radiation Performance Standard according to the Food, Drug and Cosmetic Act of 1990. Compliance is mandatory for Laser products marketed in the United States and is reported to the Center for Devices and Radiological Health (CDRH) of the U.S. Food and Drug Administration of the U.S. Department of Health and Human Services (DHHS). This means that the device does not produce hazardous laser radiation.

The label shown on page 1-12 indicates compliance with the CDRH regulations and must be attached to laser products marketed in the United States.

### **^**CAUTION

Use of controls, adjustments or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.

This is a semiconductor laser. The maximum power of the laser diode is 22 mW and the wavelength is 770-800 nm.

### For European users

### **⚠CAUTION**

Use of controls, adjustments or performance of procedures other than those specified in this manual may result in hazardous radiation exposure.

This is a semiconductor laser. The maximum power of the laser diode is 22 mW and the wavelength is 770-800 nm.

### For Denmark users

### **ADVARSEL**

Usynlig laserstråling ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling. Klasse 1 laser produkt der opfylder IEC60825 sikkerheds kravene.

Dette er en halvlederlaser. Laserdiodens højeste styrke er 22 mW og bølgelængden er 770-800 nm.

### For Finland, Sweden users

**LOUKAN 1 LASERLAITE** 

KLASS 1 LASER APPARAT

### **AVAROITUS**

Laitteen Käyttäminen muulla kuin tässä käyttöohjeessa mainitulla tavalla saattaa altistaa käyttäjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteilylle.

Tämä on puolijohdelaser. Laserdiodin sunrin teho on 22 mW ja aallonpituus on 770-800 nm.

### **^**NVARNING

Om apparaten används på annat sätt än i denna bruksanvisning specificerats, kan användaren utsättas för osynlig laserstrålning, som överskrider gränsen för laserklass 1.

Det här är en halvledarlaser. Den maximala effekten för laserdioden är 22 mW och våglängden är 770-800 nm.

### **NVAROITUS**

Avattaessa ja suojalukitus ohitettaessa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen.

### **↑**VARNING

Osynlig laserstrålning när denna del är öppnad och spärren är urkopplad. Betrakta ej strålen

### For Norway users


### **⚠ADVARSEL!**

Dersom apparatet brukes på annen måte enn spesifisert i denne bruksanvisning, kan brukeren utsettes for unsynlig laserstråling som overskrider grensen for laser klass 1.

Dette en halvleder laser. Maksimal effekt till laserdiode er 22 mW og bølgelengde er 770-800 nm.

### Laser safety label

A laser safety label is attached to the outside of the machine, as shown below.



### **Ozone Release**

During print operation, a small quantity of ozone is released. This amount is not large enough to harm anyone adversely. However, be sure the room where the machine is being used has adequate ventilation, especially if you are printing a high volume of materials, or if the machine is being used continuously over a long period.

### Dégagement d'ozone

En cours de fonctionnement, l'imprimante ne dégage qu'une faible quantité d'ozone, insuffisante pour provoquer un quelconque malaise personnel. Veillez cependant à ce que la pièce dans laquelle la machine est installée soit aérée de manière adéquate, notamment si vous imprimez de gros volumes ou si l'imprimante est longtemps utilisée en continu.

### Acoustic noise (for European users only)

Der höchste Schalldruckpegel beträgt 70 dB(A) oder weniger gemäß EN ISO 7779.

### **Notification for US only**

Contains Mercury in the LCD control panel backlighting lamp, and/or in the scanning unit lamp. Dispose According to Local, State or Federal Laws.

1-12 [Quick Start Guide]

1.3

### **Notification for California Customers**

This product uses a CR Lithium Battery which contains perchlorate material.

This perchlorate warning applies to perchlorate-containing lithium batteries sold or distributed in California, USA.

"Perchlorate Material - Special handling may apply, See www.dtsc.ca.gov/hazardouswaste/perchlorate."

### Recycling batteries (For Taiwan Users Only)

根據地方規定處理使用的電池。



### For EU member states only



This symbol means: Do not dispose of this product together with your household

Please refer to the information of your local community or contact our dealers regrading the proper handling of end-of-life electric and electronic equipments. Recycling of this product will help to conserve natural resources and prevent potential negative consequences for the environment and human health caused by inappropriate waste handling.

### For EU member states only

This product complies with RoHS (2011/65/EU) Directive.

### **USB Host**

Connect USB devices (Memory, Authentication, Hub etc.) devices directly to the USB host. If an extension cable is used, electromagnetic interference could occur.

### 1.4 Regulatory notices for telecommunication terminal equipment

This section contains regulatory information pertaining to products that contain telecommunication terminal equipment such as facsimile.

### 1.4.1 Special Notice to User

### For Canada

### NOTICE:

This product meets the applicable Industry Canada technical specifications. The Ringer Equivalence Number is an indication of the maximum number of devices allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices does not exceed five.

### AVIS:

Le present materiel est conforme aux specifications techniques applicables d'Industrie Canada.

L'indice d'equivalence de la sonnerie (IES) sert a indiquer le nombre maximal de terminaux qui peuvent etre raccordes a une interface telephonique. La terminaison d'une interface peut consister en une combinaison quelconque de dispositifs, a la seule condition que la somme d'indices d'equivalence de la sonnerie de tous les dispositifs n'excede pas 5.

### For U.S.A.

### **FCC PART 68 REQUIREMENTS:**

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the cover of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If required, this information must be provided to the telephone company.

This equipment uses certification jack USOC RJ11C.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA.

A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation guide for details.

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0).

To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US: US:AAAEQ##TXXXX.. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

1-14 [Quick Start Guide]

Introduction

If trouble is experienced with this equipment, for repair or warranty information, please contact the Konica Minolta dealer location where you purchased this equipment. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information. If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment does not disable you alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device, including FAX machines, to send any message unless such message clearly contains in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business or other entity, or other individual sending the message and the telephone number of the sending machine or such business, other entity, or individual.

(The telephone number provided may not be a 900 number or any other number for which charges exceed local or longdistance transmission charges.)

WARNING/CAUTION Explained

### **MARNING**

The exclamation point within an equilateral triangle followed by the word "Warning" is intended to alert the user to the possibility that a disregard for the warning may result in fatal hazards or critical injuries. Be sure to focus your attention on the Warning headings when reading the User's Guide.

### **CAUTION**

The exclamation point within an equilateral triangle followed by the word "Caution" is intended to alert the user to the possibility that a disregard for the caution may result in minor injuries or in physical damage. Be sure to focus your attention on the Caution headings when reading the User's Guide.

### For New Zealand

- 1. This device is equipped with pulse dialing while the Telecom standard is DTMF tone dialing. There is no guarantee that Telecom lines will always continue to support pulse dialing.
- 2. This equipment does not fully meet Telecom's impedance requirements. Performance limitations may occur when used in conjunction with some parts of the network. Telecom will accept no responsibility should difficulties arise in such circumstances.
- 3. The grant of a Telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.
- 4. The automatic calling functions of this equipment must not be used to cause a nuisance to other customers
- 5. Telepermitted equipment only may be connected to the auxiliary telephone port. The auxiliary port is not specifically designed for 3-wire connected equipment. 3-wire might not respond to incoming ringing when connected to this port.
- 6. [Administrator Settings] [Fax Settings] [Line Parameter Setting] [Number of RX Rings] setting must be configured between 2 and 7.

### **For Europe**

The Facsimile has been approved in accordance with Council Decision 1999/5/EC for pan-European single terminal connection to the public switched telephone network (PSTN). However, due to differences between the individual PSTNs provided in different countries, the approval does not, of itself, give an unconditional assurance of successful operation on every PSTN network terminal point.

In the event of problems, you should contact your equipment supplier in the first instance.



1-16 [Quick Start Guide]

### 1.5 Regulatory notices for wireless products

This section contains the following regulatory information pertaining to wireless products that contain transmitters, for example, but not limited to, wireless network cards or proximity card readers.

### Modular component notice

Wireless-equipped models contain the following modular component(s): Lexmark Regulatory Type/Model LEX-M01-005; FCC ID:IYLLEXM01005; IC:2376A-M01005

### **Exposure to radio frequency radiation**

The following notice is applicable if your printer has a wireless network card installed: The radiated output power of this device is far below the radio frequency exposure limits of the FCC and other regulatory agencies. A minimum separation of 20 cm (8 inches) must be maintained between the antenna and any persons for this device to satisfy the RF exposure requirements of the FCC and other regulatory agencies.

### **Notice to users in Brazil**

Este equipamento opera em carater secundario, isto e, nao tem direito a protecao contra interferencia prejudicial, mesmo de estacoes do mesmo tipo, e nao pode causar interferencia a sistemas operando em carater primario. (Res.ANATEL 282/2001).

### **Industry Canada (Canada)**

This device complies with Industry Canada specification RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device has been designed to operate only with the antenna provided. Use of any other antenna is strictly prohibited per regulations of Industry Canada.

To prevent radio interference to the licensed service, this device is intended to be operated indoors and away from windows to provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing.

The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF fields in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's Web site www.hc-sc.gc.ca/rpb.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

### **Industry Canada (Canada)**

Cet appareil est conforme à la norme RSS-210 d'Industry Canada. Son fonctionnement est soumis aux deux conditions suivantes :

(1) cet appareil ne doit pas provoquer d'interférences et (2) il doit accepter toute interférence reçue, y compris celles risquant d'altérer son fonctionnement.

Cet appareil a été conçu pour fonctionner uniquement avec l'antenne fournie. L'utilisation de toute autre antenne est strictement interdite par la réglementation d'Industry Canada.

En application des réglementations d'Industry Canada, l'utilisation d'une antenne de gain supérieur est strictement interdite.

Pour empêcher toute interférence radio au service faisant l'objet d'une licence, cet appareil doit être utilisé à l'intérieur et loin des fenêtres afin de garantir une protection optimale.

Si le matériel (ou son antenne d'émission) est installé à l'extérieur, il doit faire l'objet d'une licence.

L'installateur de cet équipement radio doit veiller à ce que l'antenne soit implantée et dirigée de manière à n'émettre aucun champ HF dépassant les limites fixées pour l'ensemble de la population par Santé Canada. Reportez-vous au Code de sécurité 6 que vous pouvez consulter sur le site Web de Santé Canada www.hc-sc.gc.ca/rpb.

Le terme " IC " précédant le numéro de d'accréditation/inscription signifie simplement que le produit est conforme aux spécifications techniques d'Industry Canada.

### Notice to users in the European Union

This product is in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC, 1999/5/EC, and 2009/125/EC on the approximation and harmonization of the laws of the Mem-

ber States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits, radio equipment and telecommunications terminal equipment and on the ecodesign of energy-related products.

Compliance is indicated by the CE marking.

( (

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA.

The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

This product satisfies the Class B limits of EN 55022 and safety requirements of EN 60950-1.

Products equipped with 2.4GHz Wireless LAN option are in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC, 1999/5/EC, and 2009/125/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits and on radio equipment and telecommunications terminal equipment and on the ecodesign of energy-related products.

Compliance is indicated by the CE marking.



Operation is allowed in all EU and EFTA countries, but is restricted to indoor use only.

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA.

The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

This product may be used in the countries indicated in the table below.

AT	BE	BG	CH	CY	CZ	DE	DK	EE
EL	ES	FI	FR	HR	HU	IE	IS	IT
LI	LT	LU	LV	MT	NL	NO	PL	PT
RO	SE	SI	SK	TR	UK			


Hereby, Lexmark International, Inc., declares that this type of equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

1-18 [Quick Start Guide]

1.6

### 1.6 Caution notations and labels

Safety precaution notations and labels appear on this machine at the following positions. Be very careful that an accident does not occur when operations such as removing paper jams and staple jams are performed.




### NOTICE

Do not remove caution labels or notations. If any caution label or caution notation is soiled, please clean to make legible. If you cannot make them legible, or if the caution label or notation is damaged, please contact your service representative.

### 1.7 **Space requirements**


To ensure that machine operation, consumables replenishing, part replacement, and regular maintenance can easily be performed, adhere to the recommended space requirements detailed below.

### Front view



### Right view (with optional devices installed)

The hatched parts indicate optional devices in this figure.



Unit: inch (mm)

1-20 [Quick Start Guide]

### 1.8 Operation precautions

To ensure the optimum performance of this machine, observe the precautions described below.

### Power source

The power source requirements are as follows.

- Voltage fluctuation: Maximum + 6%/- 10% (at 110V to 127V AC), ± 10% (at 220V to 240V AC)
- Frequency fluctuation: Maximum ± 3 Hz (at 50 Hz/60 Hz)
- Use a power source with as little voltage or frequency fluctuations as possible.

### Operating environment

The environmental requirements for correct operation of the machine are as follows.

- Temperature: 50°F (10°C) to 86°F (30°C) with fluctuations of no more than 18°F (10°C) within an hour
- Humidity: 15% to 85% with fluctuations of no more than 10% within an hour

### Storage of copies

To store copies, follow the recommendation listed below.

- Copies that are to be kept for a long time should be kept where they are not exposed to light in order to prevent them from fading.
- Adhesive that contains solvent (e.g., spray glue) may dissolve the toner on copies.
- Color copies have a thicker layer of toner than normal black-and-white copies. Therefore, when a color copy is folded, the toner at the fold may peel off.

### Data stored in this machine


For the machine with hard disk, it is suggested to delete all data stored in all hard disk areas using the overwrite all data function to prevent leakage of data prior to transfer or disposal of the machine, or returning of the leased machine.

For details of the overwrite all data function, refer to the User's Guide CD. Contact your service representative before deleting data.

It is recommended to backup HDD periodically as the measures for HDD defect. For the detail information of HDD backup, contact your service representative.

### **Precautions for Carrying the Machine**

This machine weighs approximately 75-5/8 lb (34.3 kg), including consumables. Two people are always required to lift the machine.



### 1.9 Legal restrictions on reproduction

Certain types of originals must never be reproduced with the purpose or intent to pass reproductions of such originals off as the originals.

The following is not a complete list, but is meant to be used as a guide to responsible reproduction.

<Financial Instruments>

- Personal checks
- Traveler's checks
- Money orders
- Certificates of deposit
- Bonds or other certificates of indebtedness
- Stock certificates

### <Legal Originals>

- Food stamps
- Postage stamps (canceled or uncanceled)
- Checks or drafts drawn by government agencies
- Internal revenue stamps (canceled or uncanceled)
- Passports
- Immigration papers
- Motor vehicle licenses and titles
- House and property titles and deeds

### <General>

- Identification cards, badges, or insignias
- Copyrighted works without permission of the copyright owner

In addition, it is prohibited under any circumstances to reproduce domestic or foreign currencies, or works of art without permission of the copyright owner.

When in doubt about the nature of an original, consult with legal counsel.

### NOTICE

This machine provides the forgery prevention function in order to prevent financial instruments from being reproduced illegally.

We appreciate your understanding that printed images may infrequently have some noise or image data may not be stored under certain circumstances due to this forgery prevention function.

1-22 [Quick Start Guide]

### 2 About Manuals

### 2 About Manuals

### 2.1 About Manuals

This guide describes basic procedures required to use this machine and how to configure initial settings. For information on the detailed functions and operation procedures, refer to the user's guide included in the **User's Guide CD-ROM**.

To use this product safely, be sure to read Chapter 1 "Introduction" before using this machine.

2-2 [Quick Start Guide]

### 2.2 **User's Guides**

### **Booklet manuals**

Manual title	Overview
[Installation Guide]	This guide describes the items required to use this machine for the first time, for example, how to place this machine or how to install the printer driver.
[Quick Start Guide] (This guide)	This guide describes notes and precautions that should be followed in order to use this machine safely. Please be sure to read this manual before using this machine.  This guide also describes how to perform basic operations and configure initial settings of this machine.

### User's guides included in User's Guide CD-ROM

Manual title	Overview
[User's Guide: Introduction]	This guide contains information that is useful to know before beginning to operate this machine, such as the name of each part and how to turn the power on and off, use the <b>Control Panel</b> , and load an original or paper.
[User's Guide: Print Functions]	This guide describes how to install the printer driver as well as basic usage and applications.
[User's Guide: Copy Functions]	This guide describes various methods to make copies.
[User's Guide: Scan Functions]	This guide describes scan transmission operations and necessary preparations. You can scan a paper document, convert it to digital data, and send the result to the computer or server.
[User's Guide: Fax Functions]	This guide describes fax operations and necessary preparations.
[User's Guide: PC-FAX Functions]	This guide describes PC- Fax operations and necessary preparations. You can send the original data created on the computer by fax directly without printing it out to paper.
[User's Guide: Advanced Functions]	This guide describes how to install optional license kits and functions that can be used by installing the license kits.
[User's Guide: Maintenance/Trouble-shooting]	This guide describes how to replace consumables, clean this machine, and perform troubleshooting.
[User's Guide: Description of Utility Keys]	This guide describes Utility settings such as [User Settings] and [Admin Settings] for this machine.
[User's Guide: Applied Functions]	This guide describes the special usages of this machine such as how to use <b>Web Connection</b> , manually install the printer driver, configure print settings using Linux, and use the authentication unit.

## About Manuals

### 2.3 **User's Guide CD-ROM**

The User's Guide CD-ROM is included in the machine package. The CD-ROM includes the user's guides required to use this machine.

From the top page, click the button of the desired user's guide. The PDF file of the user's guide opens.

### 2.3.1 **Operating environment**

Item	Description
Supported operating systems	Microsoft Windows Vista (SP2) / Windows 7 (SP1) / Windows 8 / Windows 8.1 Apple Mac OS X 10.6/10.7/10.8/10.9
Supported browsers*	For Windows Internet Explorer 7.x/8.x/9.x/10.x (desktop versions)/11.x (desktop versions) Firefox 18 or later For Mac OS safari 4.x/5.x/6.x/7.x
Required application	For Windows  • Adobe Reader 9.x/10.x/11.x  For Mac OS  • Adobe Reader 8.x/9.x/10.x/11.x
Display resolution	1024 × 768 pixels or more

<sup>\*</sup> JavaScript must be enabled.

### 2.3.2 Displaying the top page

### **For Windows**

In Windows Vista/7, inserting the CD into the CD-ROM drive of the computer displays auto play messages. Clicking [rundll32.exe] displays the top page.

In Windows 8/8.1, a message appears to prompt you to select a disk operation when the CD is inserted into the CD-ROM drive of the computer. Clicking [index\_win.exe] displays the top page.

### For Mac OS

Double-click the CD icon on the desktop and [index.html] in sequence; the top page appears.

2-4 [Quick Start Guide]

### 2.4 Notations and symbols used in this manual

### **Procedural instruction**

- This check mark symbol shows a precondition of a procedure.
- This format number "1" represents the first step.
- 2 This format number represents the order of consecutive steps.
  - → This symbol indicates a supplementary explanation of a procedural instruction.

### Symbols used in this manual

### **NOTICE**

This symbol indicates a risk that may result in damage to this machine or documents. Follow the instructions to avoid property damage.



This symbol indicates supplemental information of a topic as well as options required to use a function.

### Reference

This symbol indicates reference functions related to a topic.

### Related setting

This shows the settings related to a particular topic for any user.

### Related setting (for the administrator)

This shows the settings related to a topic only for administrators.

### **Product and key names**

Notations used in this manual	Description
[]	This presents a key name in the <b>Message Window</b> or computer screen, or the name of a user's guide.
Bold text	This presents a key name, part name, product name, or option name on the <b>Control Panel</b> .

### **Notations of application names**

This manual describes application names as shown below.

Application name	Notations used in this manual	
PageScope Direct Print	Direct Print	
PageScope Web Connection	Web Connection	
PageScope Data Administrator	Data Administrator	
PageScope Mobile (for iPhone/iPad/Android)	Mobile (for iPhone/iPad/Android)	

2-6 [Quick Start Guide]


## 3 Overview of This Machine

### 3 Overview of This Machine

### 3.1 About This Machine

### 3.1.1 Name of each part

### Front side



No.	Name
1	Control Panel
2	Automatic Document Feeder (ADF)
2-a	ADF Feed Cover
2-b	Document Guide
2-c	Document Feed Tray
2-d	Extension Tray
2-е	Document Output Tray
2-f	Document Stopper
3	USB Host Port
4	Manual Feed Tray
5	Tray 1




• To scan the legal-size original using the **ADF**, fold the **Document Stopper** outward.

3-2 [Quick Start Guide]


### Rear side

This view shows the machine with the optional  ${\it Fax}$  Kit  ${\it FK-512}$  and  ${\it Mount}$  Kit  ${\it MK-P04}$  installed.



No.	Name
1	Power Switch
2	Power Connection
3	USB Port (for authentication unit)
4	Ethernet (LAN) Port (1000Base-T/100Base-TX/10Base-T)
5	USB Port (Type B)
6	LINE (telephone line) Jack
7	TEL (telephone) Jack

## 3.1.2 Option configuration



No.	Name	Description
1	Authentication Unit AU-201/AU-201S	Performs user authentication by scanning information recorded on the IC card or the NFC-compatible mobile terminal (Android terminal).
2	Paper Feed Unit PF- P14	Allows you to load up to 500 sheets.
The fol	lowing optional component	s are built into this machine and are not shown in the figure above.
3	Hard Disk HD-P06	Increases the HDD capacity and extends functions.
4	i-Option LK-106	Used to add a bar code font, which is one of special fonts. This function is available when an optional <b>Hard Disk</b> is installed.
5	i-Option LK-107	Used to add a unicode font, which is one of special fonts. This function is available when an optional <b>Hard Disk</b> is installed.
6	i-Option LK-108	Used to add an OCR font, which is one of special fonts. This function is available when an optional <b>Hard Disk</b> is installed.
7	i-Option LK-111	Supports the ThinPrint function, which is one of a number of advanced functions.
8	Fax Kit FK-512	Used to operate this machine as a fax machine.
9	Mount Kit MK-P04	Required when installing the Fax Kit FK-512.
10	Network Interface Card NC-P03	Used to make this machine available in a wireless network environment.
11	Mount Kit MK-P07	This unit is required to install the <b>Network Interface Card</b> .




For details on how to register **i-Option** license kits, refer to Chapter 2 "Registering License Kits" in [User's Guide: Advanced Functions].

3-4 [Quick Start Guide]

#### 3.2 About Power Supply

#### 3.2.1 Turning the Power Switch ON or OFF

- 1 Connect the power cable to this machine.
- 2 Connect the power cable to the power outlet.
- When turning the main power on, press | of the **Power Switch**.



This displays the screen showing that the machine is running the start-up process.

When the main screen appears, this machine is ready to operate.

When turning the main power off, press ○ of the **Power Switch**.

#### NOTICE

While printing, do not turn the **Power Switch** off or press the **Power** key. Otherwise, it may lead to a paper jam.

If the **Power Switch** is turned off or the **Power** key is pressed while this machine is running, the system deletes the currently loaded data or communicating data as well as queued jobs.

When restarting this machine, turn the **Power Switch** off and on again after 10 or more seconds have elapsed. Not doing so may result in an operation failure.

[Quick Start Guide] 3-5

#### 3.2.2 Switching to Power Save mode

Hold down the Scan/Sleep or Copy/Power key to switch this machine to Power Save mode.

When each key is held down, the status of this machine changes as shown below.

Key	Status of this ma-chine	Status of Start Indi- cator	Print / Fax RX	Description
Scan/Sleep	Sleep	Flash: Blue	Enable	Turns off the backlight of the <b>Message Window</b> to reduce power consumption. If a fax or print job is received, it is printed while Sleep mode is maintained in the active state.  Operating the <b>Control Panel</b> returns to Normal mode.
	Deep Sleep	Flash: Blue	Enable	Reduces power consumption further than when in Sleep mode. The display of the Message Window is turned off completely. If a fax or print job is received, this machine shifts to Sleep mode to make prints, then returns to Deep Sleep mode. The time required to return to Normal mode is longer than that required to return from Sleep mode. Operating the Control Panel returns to Normal mode.
Copy/Pow- er	ErP Auto Power OFF	Flash: Orange	Disable	This function provides a more significant power saving effect than Deep Sleep mode, which is close to the state where the main power is turned off. To enable the machine to return to Normal mode from the ErP Auto Power OFF status, press the <b>Copy/Power</b> key again.



If this machine is switched to Sleep mode in factory settings, it automatically shifts to Deep Sleep mode that reduces power consumption further than when in Sleep mode.

However, this machine cannot be shifted to Deep Sleep mode if:

- An optional i-Option LK-111 is employed and the ThinPrint function is enabled.
- An optional Authentication Unit is connected.

## Related setting (for the administrator)


When this machine is in Sleep mode, you can select whether or not to shift to Deep Sleep mode that reduces power consumption further than when in Sleep mode.

To configure settings: [UTILITY] - [Admin Settings] - [System Settings] - [Pwr Sup/Pwr Sav] - [Pwr Cons Sleep Md] (Default: [Enabled])

3-6 [Quick Start Guide]

#### 3.3 Control Panel

The **Control Panel** on the top of this machine allows you to directly operate this machine. The **Message Window** displays a message that indicates the status of this machine or the required operations.



No.	Name	Description
1	Addressbook	Recalls the registered target destination (Favorites, Address Book, Group, or Program).
2	Auto RX Indicator	Lights up when the fax receiving mode is set to Auto RX.
3	Message Window	Displays Utility items or messages.
4	Error Indicator	Lights up when an error has occurred. It also flashes when a service call has occurred.
5	Fax/Access	<ul> <li>Shifts to Fax mode. Lights up green in Fax mode.</li> <li>If user authentication is enabled on this machine, hold down this key to log in or log out. For details, refer to Chapter 8 "Login Screen" in [User's Guide: Introduction].</li> </ul>
6	Scan/Sleep	<ul> <li>Shifts to Scan mode. Lights up green in Scan mode.</li> <li>Holding down this key shifts to Sleep mode. For details, refer to page 3-6.</li> </ul>
7	Copy/Power	<ul> <li>Shifts to Copy mode. Lights up green in Copy mode.</li> <li>Holding down this key shifts to ErP Auto Power Off mode. For details, refer to page 3-6.</li> </ul>
8	Stop/Reset	Cancels a changed setting or stops a function.
9	Start (Color)	Starts copying, scanning, or sending a fax in color.
10	Start Indicator	<ul> <li>Indicates the status of this machine via the lamp color, flashing, or a lamp lighting up.</li> <li>Lights up blue: This machine is ready to begin operating.</li> <li>Flashes blue: This machine is in Power Save mode, but it can receive faxes or execute print jobs.</li> <li>Flashes orange: This machine is not ready to begin operating because it is in Power Save mode.</li> <li>Lights up orange: This machine is not ready to begin operating.</li> </ul>
11	Start (B&W)	Starts copying, scanning, or sending a fax in black and white.
12	Keypad	Enter the number of copies. Also, enter the fax number, E-mail address, name, and other items. For details on how to enter characters, refer to page 3-11.
13	Back	<ul> <li>Cancels the entered character or numeric value.</li> <li>Returns to the previous screen.</li> <li>Cancels the displayed setting.</li> </ul>

[Quick Start Guide] 3-7

3


No.	Name	Description
14	<b>4</b> /▶	Moves the cursor right or left.
15	Select	Determines the selected menu item.
16	▲/▼	Moves the cursor up or down.
17	On hook	Places the machine into the off-hook mode. Pressing this key again returns to the on-hook mode.
18	Redial/Pause	<ul> <li>Displays the fax number to which the last fax was sent by specifying the destination using Direct Input.</li> <li>Inserts a pause into the fax number to be used for sending.</li> </ul>

3-8 [Quick Start Guide]

#### **Screen Layout** 3.4


#### 3.4.1 Main screen

## Copy mode



No.	Display	Details
1	Copier settings	Check the current setting or change various settings. For details, refer to [User's Guide: Copy Functions].
2	Status	Displays a message depending on your operating status.
3	Copy density	Displays the copy density.
4	Number of copies	Displays the number of copies.


#### Scan mode



No.	Display	Details
1	Scan settings	Check the current setting or change various settings. For details, refer to [User's Guide: Scan Functions].
2	Status	Displays a message depending on your operating status.
3	Free space	Displays the free memory space in percentage form (%).

[Quick Start Guide] 3-9

#### Fax mode



No.	Display	Details
1	Time	Displays the current time.  To specify the time, select [UTILITY] - [Admin Settings] - [System Settings] - [CLOCK].
2	Free space	Displays the free memory space in percentage form (%).
3	Fax settings	Check the current setting or change various settings. For details, refer to [User's Guide: Fax Functions].
4	Status	Displays a message depending on your operating status.

#### 3.4.2 Help screen

If an error such as a paper jam has occurred, press the ▶ key; the help screen appears to help you perform error processing.

3-10 [Quick Start Guide]

#### 3.5 Entering Characters

Enter digits, characters, and symbols using the Keypad.

#### Changing the entry mode

The entry mode shifts in the order of alphabet characters -> digits each time the \*Key on the Control Panel is pressed.

Display	Description
[A]	Alphabet character entry mode
[1]	Digit entry mode

#### **Available characters**

The available characters vary depending on the entry mode. The following characters are available in each entry mode.

Keypad	[1] Digit entry mode	[A] Alphabet character entry mode
1	1	.,'?!"1-()@/:;_
2	2	ABC2abc
3	3	DEF3def
4	4	GHI4ghi
5	5	JKL5jkl
6	6	MNO6mno
7	7	PQRS7pqrs
8	8	TUV8tuv
9	9	WXYZ9wxyz
0	0	(space)0
#	#	+&/*=!?()%[]^`´{} \$,:



- On the fax number entry screen, an asterisk, "\*", is displayed if the \*key is pressed.
- To delete all characters you entered, hold down the **Back** key.
- To delete some characters you entered, press the ◀ or ▶ key to move the cursor to the character you want to delete, then press the Back key.
- To continuously enter characters using the same key, type the first character, then press the ▶ key to type the next character.
- To enter a space, press the **0** key once in the alphabet character entry mode.

[Quick Start Guide] 3-11

3

[Quick Start Guide] 3-12

# 4 Loading Paper

## **Loading Paper**

#### 4.1 **Paper**

#### 4.1.1 Checking the available paper types

Paper type	Paper weight	Paper capacity
Plain paper Recycled paper Two-side unavailable paper*1	15-15/16 lb to 23-15/16 lb (60 g/m² to 90 g/m²)	Manual Feed Tray: 100 sheets Tray 1: 250 sheets
Thick 1	24-3/16 lb to 39-7/8 lb (91 g/m² to 150 g/m²)	Manual Feed Tray: 20 sheets Tray 1: 20 sheets
Thick 2	40-3/16 lb to 55-7/8 lb (151 g/m <sup>2</sup> to 210 g/m <sup>2</sup> )	Manual Feed Tray: 20 sheets Tray 1: 20 sheets
Glossy paper 1	26-5/8 lb to 34-1/16 lb (100 g/m <sup>2</sup> to 128 g/m <sup>2</sup> )	Manual Feed Tray: 20 sheets Tray 1: 20 sheets
Glossy paper 2	34-5/16 lb to 42 lb (129 g/m <sup>2</sup> to 158 g/m <sup>2</sup> )	Manual Feed Tray: 20 sheets Tray 1: 20 sheets
Postcard	-	Manual Feed Tray: 20 sheets Tray 1: 20 sheets
Envelope	-	Manual Feed Tray: 10 sheets
Label sheet	-	Manual Feed Tray: 20 sheets Tray 1: 20 sheets
Letterhead*2	-	Manual Feed Tray: 20 sheets Tray 1: 20 sheets

<sup>&</sup>lt;sup>\*1</sup> Paper on which you will not print on both sides (for example, when something has already been printed on the front side).

Paper other than plain paper is referred to as special paper. When loading special paper into the paper tray, specify the correct paper type. Otherwise, it may result in a paper jam or image error.



You can select whether or not to allow printing on both sides of letterhead paper in [Letterhead Duplex] of this machine (default: [RESTRICT]). To allow printing on both sides of letterhead paper, use plain paper as the letterhead paper type.

4-2 [Quick Start Guide]

<sup>\*2</sup> Paper where company names, preset text, and other text have already been printed.

#### 4.1.2 Checking the available paper sizes

Paper feed port	Allowable sizes
Manual Feed Tray	A4, A5, A6, B5 (JIS), B6 Legal (8-1/2 × 14), Letter (8-1/2 × 11), SP Folio (8-1/2 × 12-11/16), Executive (7-1/4 × 10-1/2), Invoice (5-1/2 × 8-1/2) Foolscap (8 × 13), 8-1/8 × 13-1/4, Folio (8-1/4 × 13), Government Legal (8-1/2 × 13), 8-1/2 × 13-1/2, 16K, Kai 16, Kai 32 Postcard (100 mm × 148 mm), Reply postal card (148 mm × 200 mm) Photo Size 4 × 6 Envelope #10, Western-style envelope #6, Envelope DL, Western-style envelope #2, End-opening envelope #3, End-opening envelope #4 B5 (ISO), UK Quarto (8 × 10), Government letter (8 × 10-1/2) Width: 3-5/8 to 8-1/2 inches (92.0 mm to 215.9 mm), Length: 5-13/16 to 14 inches (148.0 mm to 355.6 mm)
Tray 1	A4, A5, A6, B5 (JIS), B6 Letter (8-1/2 × 11), Executive (7-1/4 × 10-1/2), Invoice (5-1/2 × 8-1/2) , Government legal (8-1/2 × 13) 16K, Kai 16, Kai 32, Postcard (100 mm × 148 mm), Reply postal card (148 mm × 200 mm) Photo Size 4 × 6 UK Quarto (8 × 10), Government letter (8 × 10-1/2) Width: 3-5/8 to 8-1/2 inches (92.0 mm to 215.9 mm), Length: 5-13/16 to 11-11/16 inches (148.0 mm to 297.0 mm)



- When printing is carried out, the area with the exception of a 3/16 inch (4.2 mm) border around the edges of the paper, is used as the printable area on all sizes of paper. When configuring a user setting of the page size using the application, specify the paper size within the printable area so that the optimal result is obtained.
- On an envelope, it is only possible to print on the front (address) side. Also, the result of printing on the seal overlapping part on the front side cannot be assured. The area that cannot be assured varies depending on envelope types.
- The page margin setting is determined depending on your application. If the default paper size or margin is selected, there may be some part of the paper that is not able to be printed on. To obtain the optimal result, configure the custom size setting so that an image is included in the printable area of this machine.
- Specify the custom size in the range of the numeric values shown in the table above using the printer driver.
- When custom-size paper with dimensions larger than width 8-1/4 inches (210 mm) and length 11 inches (279 mm) is used in Tray 1, trailing edges will be loaded in the bent state due to the tray structure. (Maximum length 11-11/16 inches (297 mm)) To load such custom-size paper, use the Manual Feed Tray or load up to 100 sheets in Tray 1.
- In Mac OS X environment, the maximum size of the **Manual Feed Tray** that can be used for 2-sided printing is "width 8-1/2 inches (216 mm) x length 14 inches (355 mm)".

[Quick Start Guide] 4-3

#### 4.1.3 **Precautions for correct operations**

#### Unavailable paper

Do not load the following types of paper into the tray. Not observing these precautions may lead to reduced print quality, a paper jam, or machine damage.

- Paper that has been printed on using a heat-transfer printer or an inkjet printer
- Folded, curled, wrinkled, or torn paper
- Paper that has been left unwrapped for a long period of time
- Paper that is damp, perforated, or that has been hole punched
- Extremely smooth or extremely rough paper, or paper with an uneven surface
- Treated paper such as carbon-backed paper, thermal paper, pressure-sensitive paper, or iron-on transfer paper
- Paper that has been decorated with foil or embossing
- Paper of a non-standard shape (paper that is not rectangular)
- Paper that is bound with glue, staples or paper clips
- Paper with labels attached
- Paper with ribbons, hooks, buttons, etc., attached
- Paper with different paper quality (roughness) on the front and back sides
- Paper that is too thin or too thick
- Paper containing static electricity
- Acidic paper
- Other types of unavailable paper

#### Storing paper

To store paper, be sure to note the following points.

- Store paper on an even, horizontal surface, and do not take the paper out of its packaging until it is loaded into a tray. If paper is left for a long period of time outside its package, it may cause a paper jam.
- When not using paper that has been taken out of its package once, return it to the original package and store it in a horizontal, cool, dark place.
- Do not store paper in locations or in environments that are:
- Too humid
- Exposed to direct sunlight
- Subject to high temperatures (95°F (35°C) or more)
- Do not set paper against the other or store it vertically.



When purchasing a large quantity of paper or special paper, carry out a trial print to check the printing quality in advance.


4-4 [Quick Start Guide]

## 4.2 Loading paper into the Manual Feed Tray

When selecting a paper size other than for paper trays, use the **Manual Feed Tray**.

To use the **Manual Feed Tray**, load paper and specify the paper type.

- ✓ For details on the available paper types and sizes, refer to page 4-2.
- 1 Open the Manual Feed Tray.



2 Spread out the paper guide.



3 Push up the center of the flip-top plate until the lock latches (white) at the right and left are locked.



[Quick Start Guide] 4-5

- 4 With the side to be printed on facing down, insert the paper as far as possible into the feed slot.
  - → When loading letterheads, place the side that has the company name, fixed phrases, and other text printed on it face down.
  - → When loading letterheads while 2-sided printing on letterhead paper is allowed in [Letterhead Duplex] of this machine, place the side that has the company name, fixed phrases, and other text printed on it face up.



#### **NOTICE**

Load paper within the guide indicating the upper limit.


If paper is curled, flatten it before loading.

- 5 Align the paper guide to the paper size.
- 6 Change the paper type and paper size on the **Control Panel**. When loading custom sized paper, also specify the paper size.
  - → To configure settings: [UTILITY] [Paper Settings] [Manual]


4-6 [Quick Start Guide]

## 4.3 Loading paper into Tray 1


- ✓ For details on the available paper types and sizes, refer to page 4-2.
- ✓ Tray 2 is available when the optional Paper Feed Unit is installed. For details on how to load paper into Tray 2, refer to Chapter 6 "Loading Paper" in [User's Guide: Introduction].
- 1 Pull out Tray 1.



2 Press the flip-top plate down until it is locked.




3 Spread out the paper guide.



[Quick Start Guide] 4-7

- 4 Load paper into the tray with the print side facing up.
  - → Load a postcard or reply postal card, turning the short side to the right-hand side of the tray.
  - → When loading letterheads, place the side that has the company name, fixed phrases, and other text printed on it face up.
  - → When loading letterheads while 2-sided printing on letterhead paper is allowed in [Letterhead Duplex] of this machine, place the side that has the company name, fixed phrases, and other text printed on it face down.



#### **NOTICE**

Do not load the sheets up to the point where the top of the stack is higher than the **▼**mark. If paper is curled, flatten it before loading.

- 5 Align the paper guide to the paper size.
- 6 Close Tray 1.
- Change the paper type and paper size on the Control Panel. When loading custom sized paper, also specify the paper size.
  - → To configure settings: [UTILITY] [Paper Settings] [Tray1]

4-8 [Quick Start Guide]

# 5 Initial Settings of This Machine

## 5 Initial Settings of This Machine

## 5.1 Preparation for network connection (for administrators)

#### Checking a LAN cable for connection

Check that a LAN cable connected to the network is connected to the LAN port of this machine.

For details on the cable connection port, refer to page 3-3.

#### Assigning an IP address

If this machine has a fixed IP address, manually enter the IP address, subnet mask, and default gateway address.

In the **Control Panel**, select [UTILITY] - [Admin Settings] - [ETHERNET] - [TCP/IP] - [IPv4 Settings], then configure the following settings.

Settings	Description
[IP ADDRESS]	When manually specifying the IP address, enter the fixed IP address assigned to the machine.
[SUBNET MASK]	When manually specifying the IP address, enter the subnet mask.
[DEFAULT GATEWAY]	When manually specifying the IP address, enter the default gateway.
[IP Appl Method]	When automatically specifying the IP address, select the method for automatic retrieval.  In [DHCP]: [ON] is specified by default. In [BOOTP]: [OFF] is specified by default. In [ARP/PING]: [OFF] is specified by default. In [AUTO IP Settings]: Fixed to [ENABLE].



• To check the IP address assigned to this machine, print out the Configuration Page. To print out the Configuration Page, select [REPORT/STATUS] - [REPORT] - [Configuration Page] on the main screen.

5-2 [Quick Start Guide]

#### 5.2 Preparation for fax (for administrators)

#### Checking the modular cable connection

Check that a modular cable is connected between the LINE port and the relevant telephone line.

For details on the cable connection port, refer to page 3-3.

#### Specifying the type of telephone line

Specify the type (dialing method) of telephone line to which this machine is to be connected. The dialing method must be correctly specified to ensure communication can take place.

To configure settings: [UTILITY] - [Admin Settings] - [Fax Settings] - [Line Param Setting] - [Dialing Method]

## Preparing to use the machine in a Private Branch Exchange (PBX) environment

When you use this machine in a PBX environment, register an outside line number.

To configure settings: [UTILITY] - [Admin Settings] - [Fax Settings] - [PBX CX Settings]

#### Selecting a receiving method

Methods of receiving faxes include the following: This machine receives faxes automatically, and the user receives faxes manually. Set the receiving method to suit your environment.

To configure settings: [UTILITY] - [Admin Settings] - [Fax Settings] - [Line Param Setting] - [RX MODE]

#### Registering the sender information

Register the name of this machine and the company name (sender name) as well as the fax number of the machine.

The information you registered is added to faxes to be sent and output to faxes as a sender record when being printed on receiving machines.

To configure settings: [UTILITY] - [Admin Settings] - [Fax Settings] - [Header Information]

#### Setting the date and time for the machine

Set the date and time in this machine to have them printed on sent and received faxes. The date and time you set will be the reference time for the Timer TX that enables communication to take place at a preset time.

To configure settings: [UTILITY] - [Admin Settings] - [System Settings] - [CLOCK]

[Quick Start Guide] 5-3

#### 5.3 Hard disk (HDD) setting (for administrators)

To encrypt and protect data saved on the hard disk of this machine, configure a hard disk encryption setting.

If a hard disk encryption setting is configured, the hard disk is formatted, and data saved on the hard disk is erased. Therefore, we recommend that you finish a hard disk encryption setting before using this machine.

To configure settings: [UTILITY] - [Admin Settings] - [Security Settings] - [HDD Settings] - [HDD EncryptSetting]



This function is available when an optional Hard Disk is installed.

#### Related setting (for the administrator)

 When enabling the Enhanced Security Mode to use this machine, you need to configure a hard disk encryption setting. For details on the Enhanced Security Mode, refer to [User's Guide: Description of Utility Keys] - Chapter 6 "Admin Settings" - "EnhancedSecurityMd".

5-4 [Quick Start Guide]

# 6 Basic Usage

## 6 Basic Usage

#### 6.1 Using the print function (Windows environment)

This section describes how to configure print settings in Windows environment.

## Reference

For details on how to configure print settings in the Mac OS environment, refer to Chapter 3 "Printing in the Mac OS Environment" in [User's Guide: Print Functions].

For details on how to configure print settings in Linux environment, refer to Chapter 5 "Printing in the Linux Environment" in [User's Guide: Applied Functions].

#### 6.1.1 Printer driver

Before using this machine as a printer, you need to install the printer driver on your computer.

The following types of printer drivers are available. Select the printer driver that meets your printing aims.

Printer driver	Page description lan- guage	Description
PCL driver	PCL6	This is a standard driver for printing general office originals.  Among the three drivers, this driver provides the fastest printing speed.
PS driver	PostScript 3 Emulation	This driver is effective for high-definition printing of data created in PostScript-supporting application software from Adobe or other vendors.  This driver is often used in graphics and light printing applications where good color reproducibility is important.
XPS driver	XPS	Developed after Windows Vista, this driver supports XML Paper Specification (XPS). This driver has several advantages, including high-quality reproduction of translucence.

#### 6.1.2 Preparation for printing (network connection)

#### Checking a LAN cable for connection

Check that a LAN cable is connected to the LAN port of this machine.

For details on the cable connection port, refer to page 3-3.

#### Checking the network settings

Print out the Configuration Page, then check that an IP address is assigned to this machine.

To print out the Configuration Page, select [REPORT/STATUS] - [REPORT] - [Configuration Page] on the main screen.



If no IP address is displayed, you need to set up the network. For details, refer to page 5-2.

6-2 [Quick Start Guide]

#### Installing the printer driver

Use the installer to install the printer driver on your computer.

- Administrator privileges are required to perform this task.
- Use the Driver & Utilities CD-ROM.
- Insert the printer driver CD-ROM into the CD-ROM drive of the computer.
  - → Make sure that the installer starts, then go to Step 2.
  - → If the installer does not start, open the printer driver folder on the CD-ROM, double-click [Setup.exe], then go to Step 3.
  - → If the [User Account Control] window appears, click [Continue] or [Yes].
- 2 Click [Printer/FAX].
- 3 Read the license agreement, then click [AGREE].
- 4 Check the contents of the [Readme] window, then click [Next].
- 5 Select [Install printers/MFPs], then click [Next].


Connected printers are detected.

- → In Windows Vista/7/8/8.1/Server 2008/Server 2008 R2/Server 2012/Server 2012 R2, you can select [Preference for IPv4] or [Preference for IPv6]. The address has the preference when detected in both IPv4 and IPv6.
- Select this machine, then click [Next].
  - → If this machine is not detected, restart it.
  - You do not need to change the printing method from [Normal Printing] (Port 9100) unless otherwise specified by the administrator. This guide describes how to configure the [Normal Printing] (Port 9100) setting.
  - As the printing method, you can select [Normal Printing], [Internet Printing] (IPP), or [Secure Printing] (IPPS). For details on the printing method, refer to Chapter 2 "Printing in the Windows Environment" in [User's Guide: Print Functions].
  - → Among the connected printers, only the target model is automatically detected and displayed. If multiple target models are displayed, check the IP addresses.
  - → If the connection to this machine cannot be recognized, it is not displayed in the list. In such a case, select [Specify the Printer/MFP Except for the Above. Select (IP Address, Host Name...)], then manually specify the IP address and host name of this machine.



6-3 [Quick Start Guide]

- 7 Select the check box of the printer driver you want to install, then click [Next].
  - → For features of each printer driver, refer to page 6-2.



- 8 Check the components to be installed, then click [Install].
- 9 If necessary, change the printer name or print a test page, then click [Finish].
  The installation process of the printer driver is then completed.

Settings	Description
[Review]	Displays the installed components for checking.
[Rename Printer]	Changes this machine name, if necessary.
[Property]	Sets the optional operating environment of this machine.
[Print Setting]	Changes the default print settings of this machine, if necessary.
[Print Test page]	If necessary, print a test page to check that printing process works correctly.

#### Reference

When you finish installing the printer driver, configure the default settings of the printer driver. For details, refer to page 6-7.

#### 6.1.3 Preparation for printing (USB connection)

# Changing the installation settings (Windows 7/8/8.1/Server 2008 R2/Server 2012/Server 2012 R2)


If you are using Windows 7/8/8.1/Server 2008 R2/Server 2012/Server 2012 R2, change the computer settings before installing the printer driver.

- Open the [Control Panel] window.
  - → In Windows 8.1, click [�] in the Start window, then click [Control Panel] [Hardware and Sound] [View devices and printers].
  - → In Windows 8, right-click the Start window, then click [All apps] [Control Panel].
  - → In Windows Server 2012/Server 2012 R2, open the Start window, then click [Control Panel].
  - → In Windows 7/Server 2008 R2, open the Start menu, then click [Control Panel].
- Click [System and Security] [System].
- 3 Click [Advanced system settings] on the menu in the left-hand pane.


The [System Properties] window appears.

6-4 [Quick Start Guide]

4 In the [Hardware] tab, click [Device Installation Settings].



- 5 Select [No, let me choose what to do], select [Never install driver software from Windows Update.], then click [Save Changes].
  - → After you have installed the printer driver, change the setting back to [Yes, do this automatically (recommended)].



6 Click [OK] to close the [System Properties] window.

#### Installing the printer driver

Use the installer to install the printer driver on your computer.


- ✓ Administrator privileges are required to perform this task.
- ✓ Use the Driver & Utilities CD-ROM.
- Connect a USB cable to the USB port of this machine.
  - → For details on the cable connection port, refer to page 3-3.
  - → If a wizard window for adding new hardware opens, click [Cancel].
- Insert the printer driver CD-ROM into the CD-ROM drive of the computer.
  - → Make sure that the installer starts, then go to Step 3.
  - → If the installer does not start, open the printer driver folder on the CD-ROM, double-click [Set-up.exe], then go to Step 4.
  - → If the [User Account Control] window appears, click [Continue] or [Yes].
- 3 Click [Printer/FAX].
- 4 Read the license agreement, then click [AGREE].
- 5 Check the contents of the [Readme] window, then click [Next].
- Select [Install printers/MFPs], then click [Next].
  USB-connected printers are detected.

[Quick Start Guide] 6-5

7 Select this machine, then click [Next].



- 8 Select the check box of the printer driver you want to install, then click [Next].
  - → For features of each printer driver, refer to page 6-2.



- 9 Check the components to be installed, then click [Install].
- 10 If necessary, change the printer name or print a test page, then click [Finish].
  The installation process of the printer driver is then completed.

Settings	Description
[Review]	Displays the installed components for checking.
[Rename Printer]	Changes this machine name, if necessary.
[Property]	Sets the optional operating environment of this machine.
[Print Setting]	Changes the default print settings of this machine, if necessary.
[Print Test page]	If necessary, print a test page to check that printing process works correctly.

## Reference

When you finish installing the printer driver, configure the default settings of the printer driver. For details, refer to page 6-7.

6-6 [Quick Start Guide]


#### 6.1.4 Initial settings of the printer driver

When you use this machine for the first time, configure the printer driver so that it contains information such as what options are installed on this machine and whether or not authentication settings have been configured

- 1 Display the printer window.
  - → In Windows 8.1, click [♠] in the Start window, then click [Control Panel] [Hardware and Sound] [View devices and printers].
  - → In Windows 8, right-click the Start window, then click [All apps] [Control Panel] [Hardware and Sound] [View devices and printers].
  - → In Windows Server 2012/Server 2012 R2, open the Start window, then click [Control Panel] [Hardware] [View devices and printers].
  - → In Windows 7/Server 2008 R2, open the Start menu, then click [Devices and Printers].
  - → In Windows Vista/Server 2008, click the Start menu, and select [Control Panel] [Hardware and Sound] [Printers].
  - → In Windows Server 2003, click the Start menu, then select [Printers and Faxes].
- 2 Open the printer properties.
  - → In Windows 7/8/8.1/Server 2008 R2/Server 2012/Server 2012 R2, right-click the icon of the installed printer, and from [Printer properties], click the displayed printer name.
  - → In Windows Vista/Server 2003/Server 2008, right-click the icon of the installed printer, then click [Properties].

The [Properties] window appears.

- In the [Configure] tab, configure the information such as what options are installed on this machine and whether or not authentication settings have been configured.
  - → By default, [Auto] in [Acquire Settings...] is enabled. The information on this machine is automatically obtained and reflected to [Device Option].
  - → When [Auto] in [Acquire Settings...] is disabled, clicking [Acquire Device Information], obtains and reflects the information on this machine to [Device Option].
  - → If you cannot communicate with this machine or you are using a USB connection in Windows Server 2003 environment, manually configure a setting in [Device Option]. Select the item to change from the list, and set a value in [Setting].



4 Click [OK].

[Quick Start Guide] 6-7

#### 6.1.5 How to print

- 1 Open data of the original using the application software. From the [File] menu, select [Print].
- 2 In [Printer Name] (or [Select Printer]), make sure that the desired printer has been selected.
  - → The [Print] dialog box varies depending on the application software.



- 3 Specify the print range and the number of copies to print.
- 4 Click [Properties] (or [Preferences]) to change the print settings of the printer driver, if necessary.
  - → The print settings you have changed here return to the default values when you exit the application software.
  - → For details on the print settings of the printer driver, refer to Chapter 2 "Printing in the Windows Environment" in [User's Guide: Print Functions].
- 5 Click [Print].

Printing is executed.

6-8 [Quick Start Guide]

Basic Usage

## 6.2 Using the scan function

#### 6.2.1 Available operations in the scan function

The original data scanned by this machine can be sent to a computer or server, or saved on the hard disk of the machine.

The scan function provides the following sub-functions.

Function	Description
Scan to E-mail	Sends a converted file to any E-mail address as an E-mail attachment.
SMB Send	Sends a converted file to a shared folder of a computer. To use this function, specify your computer or file server as a destination.
FTP TX	Sends a converted file to the FTP server. This function is useful when transferring a file through the FTP server.
Save to HDD	Saves the original data scanned by this machine on the built-in hard disk. The original data saved on the hard disk can be downloaded via the Web browser on your computer.
	Note This function is available when an optional <b>Hard Disk</b> is installed.
Save to USB Memory	Saves the original data scanned by this machine in the USB memory device connected to the machine.
WS Scan	Imports original data by issuing a scan instruction from a computer without configuring complicated system settings, or sends original data scanned by this machine to a computer.  This function is supported by Windows of Vista or later.
TWAIN/WIA Scan	Converts the original data scanned by this machine into a file, and imports it from a computer on the network using TWAIN/WIA-compatible applications.




It may be necessary to make the following settings prior to using the scan function. For details on how to use each function, refer to [User's Guide: Scan Functions].

[Quick Start Guide] 6-9

#### 6.2.2 How to scan

1 Load the original.



- 2 Press the Scan key.
- 3 Specify the destination.
  - → You can select the desired destination from the pre-registered destination list, or directly enter destination information. For details on how to register a destination, refer to page 6-17.
- Specify scan transmission options.
  - → On the main screen (Scan mode), press the ▲ or ▼ key to select the setting you want to change.
- 5 Press the **Start** key.
  - → To scan in color, press the Start (Color) key. To scan in black and white, press the Start (B&W) key.
  - → If you press the **Stop/Reset** key while scanning the original, scan processing stops, and the confirmation screen appears to check whether you wish to cancel the job. To stop sending, cancel the job.

Sending starts.

6-10 [Quick Start Guide]

Basic Usage

#### 6.3 **Using Fax Functions**

#### 6.3.1 **Fax functions**

The Fax is a communication function that uses a telephone line to send scanned originals (paper) or to receive data sent from remote machines. This machine has various features for fax operations, including those enabling the user to change scan settings according to the original and to save incoming faxes in memory.

The following describes precautions that should be observed when using fax functions.


- To use the fax function, the optional Fax Kit and Mount Kit are required.
- This machine can be connected to the following types of telephone lines.
- Public switch telephone network (including fax communication line)
- PBX (Private Branch Exchange, 2-wire)
- Fax data cannot be sent or received in color.
- You cannot connect a business phone as an external telephone.
- The call waiting function cannot be used simultaneously.
- If a dedicated digital line is multiplexed in an enterprise network, fax transmission speed may be limited, or the Super G3 fax may not be available.
- Communication errors may occur on rare occasions due to factory default settings. This is because the multiplex device limits the frequency band of the line to the utmost limit based on the assumption that the line is intended for voice communication. Also, these restrictions differ depending on the devices that are connected to the network. For details, contact your network administrator.

#### Reference

To use the fax function, the operating environment must be configured on this machine in advance. For details, refer to page 5-3.


#### 6.3.2 How to Send

Load the original.



- Press the Fax key.
- 3 Enter a fax number.
  - → You can select the desired destination from the pre-registered destination list, or directly enter destination information. For details on how to register a destination, refer to page 6-17.
  - → Fax broadcasting can be performed by specifying multiple destinations.
- Specify fax transmission options.
  - → On the main screen (Fax mode), press the **A** or **V** key to select the setting you want to change.

[Quick Start Guide] 6-11



→ If you press the **Stop/Reset** key while scanning the original, scan processing stops, and the confirmation screen appears to check whether you wish to cancel the job. To stop sending, cancel the job.

Sending starts.

#### 6.3.3 Introduction of fax transmission function

This section describes convenient fax transmission functions. For details on how to use each function, refer to Chapter 4 "Sending Options" in [User's Guide: Fax Functions].

Function	Overview
Timer TX	Timer TX automatically starts sending at a specified time if the time is prespecified.
Check Dest. & Send	Check Dest. & Send checks the fax number specified for the fax transmission against the destination fax number (CSI) and sends the fax only when they match.
F-Code TX	<ul> <li>F-Code TX specifies the F code (SUB address and sending ID) to send a fax.</li> <li>Confidential communication and relay distribution request are available.</li> <li>The confidential communication function is designed to communicate with specific people using a Confidential RX User Box that requires a registered number and a password.</li> <li>Relay distribution request is a function that the relay station, which has received a fax, distributes the received fax to a pre-registered group.</li> </ul>
Quick Memory TX	Fax transmission starts concurrently with scanning one page. The total number of pages transmitted can be entered in the sender record.
Polling TX	Polling TX stores a file beforehand on the internal hard disk and sends it out upon a request for reception (polling request) from the recipient.

#### 6.3.4 Introduction of fax receiving function

This section describes the convenient fax receiving functions. For details on how to use each function, refer to Chapter 6 "Receiving Options" in [User's Guide: Fax Functions].


Function	Overview
Forward TX	Forward TX is a function that transfers a received fax to a pre-specified destination (fax or E-mail destination).
Memory RX	Memory RX saves a received fax in this machine's memory without printing it.
Polling RX	Polling RX receives a polling file saved in a sending machine as instructed from this machine.
PC-Fax RX	PC-Fax RX saves the received fax in memory. The saved fax can be printed or downloaded if necessary.
Night RX	Night RX prohibits printing of faxes received in the pre-specified nighttime zone.

6-12 [Quick Start Guide]

## 6.4 Using the copy function

#### **6.4.1** How to copy

1 Load the original.



- 2 Press the Copy key.
- 3 If necessary, configure copy settings.
  - → On the main screen (Copy mode), press the ▲ or ▼ key to select the setting you want to change.
- 4 If necessary, specify the number of copies using the **Keypad**.
  - → To re-enter the number of copies, press the **Back** key.
- 5 Press the **Start** key.

The original is scanned, and copying starts.

- → To copy in color, press the **Start (Color)** key. To copy in black and white, press the **Start (B&W)** key.
- → If you press the **Stop/Reset** key, the confirmation screen appears to check whether to cancel the job. To stop copying, cancel the job.

[Quick Start Guide] 6-13

## 6.4.2 Introduction of copy function

This section describes the convenient copy functions. For details on how to use each function, refer to [User's Guide: Copy Functions].

Function	Overview
[Original Size]	Select the size of the original to be scanned.
[Zoom]	You can copy an original image enlarged or reduced by an arbitrary zoom ratio.
[Quality] - [Original Type]	Select the optimum settings for the original to copy it at the optimum image quality level.
[Quality] - [DENSITY]	Adjust the density of a copy image.
[Quality] - [Bkgd. Re- moval]	Adjust the background density of an original with the colored background such as newspaper or an original made from recycled paper.
[Quality] - [Sharpness]	Sharpen the edges of the image to improve legibility. Smoothen the rough contour or sharpen the blurred image.
[Tray Select]	Specify the paper tray to make a copy.
[Original > Output]	Copy an original onto both sides of paper.
[ID CARD COPY]	When you want to copy cards, such as an insurance card, a driver license card and a business card, you can arrange the front and back sides of the card on a single page and copy the images on to the same side of one sheet. This can reduce the number of sheets used.
[Finishing]	You can select whether to sort the output sheets or group them when printing multiple sets of copies.
[Combine]	Copy the 1-sided original on both sides of paper, or copy the 2-sided original on both sides or on a single side of sheets of paper.
[Separate Scan]	If the number of original sheets is so large that they cannot be loaded into the <b>ADF</b> at the same time, you can load them in several batches and handle them as one job.

6-14 [Quick Start Guide]

## 6.5 Printing a file stored in USB memory



This function is available when an optional Hard Disk is installed.

#### Supported USB memory devices

USB memory devices that have the following specifications can be connected to this machine.

Item	Specifications
Supported media	USB memory device (USB 2.0 supported)
File system	FAT32
File Type	PDF, Compact PDF, JPEG, TIFF, XPS, Compact XPS, OOXML (.docx/.xlsx/.pptx), and PPML (.ppml/.vdx/.zip)



#### Zips

Note the following points when connecting a USB memory device to this machine.


- Use the USB connector on the side that is near the **Control Panel**.
- Do not disconnect the USB memory device while saving a file to the USB memory or printing a file in the USB memory.
- Only use a USB memory device on this machine. Do not use other USB devices (such as a hard disk unit or USB switching hub).
- When this machine is starting up, do not insert or remove the USB memory device to/from the USB port.
- Do not disconnect the USB memory device directly after connecting it.



However, the encrypted PDF file cannot be printed.

#### How to print

Connect a USB memory device to the USB port of this machine.



- 2 On the main screen (Copy mode), press the ▲ or ▼ key to select [USB/HDD], then press the Select key.
- 3 Select [MEMORY DIRECT], then press the **Select** key.
- 4 Select [File List], then press the **Select** key.
  - → To display a JPEG or TIFF file, select [TYPE OF FILES] in [PDF,XPS,JPEG,TIFF].
- 5 Select a file to print, then press the **Select** key.
  - → If the target file is included in a folder, select the folder.
  - → Up to 99 folders and files in all can be displayed.
  - → Folders in level 7 or higher cannot be displayed.

[Quick Start Guide] 6-15

6 If necessary, change the setting of the paper size, duplex printing, number of copies, or collate function.

Settings	Description
[PAPER SIZE]	Select the size of paper for printing. The paper size can be specified when the selected file type is TIFF or JPEG.
[DUPLEX]	Select whether or not to print data on one side or both sides of sheets of paper. To print data on both sides, select the binding position.
[COPIES]	Specify the number of copies you want to print.
[Collate]	When printing multiple copies of data, select whether or not to feed out copies separately one by one, such as in the following order: "12345", "12345", and "12345".

#### Press the Start key.

→ To print in color, press the **Start (Color)** key. To print in black and white, press the **Start (B&W)** key. Printing starts.

6-16 [Quick Start Guide]

#### 6.6 **Address Registration**

#### Address book

Registering a frequently used destination on this machine will save you the trouble of having to enter it each time you send data. A destination registered on this machine is called an Address Book.

Up to 250 address books can be registered.



Address books can also be registered using **Web Connection**. For details, refer to Chapter 2 "Configuring the Operating Environment of This Machine" in [User's Guide: Applied Functions].

#### Registering a fax destination

Register the destination fax numbers.

- Select [UTILITY] [One-Touch Reg] [Fax], then press the **Select** key.
- 2 Type in the target one-touch dial number using the **Keypad**, then press the **Select** key.
- 3 Enter [Name] (using up to 72 characters), then press the Select key.
- When setting the target destination in [Favorites] (frequently used destinations), select [YES], then press the Select key.
- Enter the destination fax number, then press the **Select** key.
  - → The available keys are number keys (0 to 9), #, and ¥.
  - → If you press the Redial/Pause key, you can insert a pause. If you insert a pause, Message Window is displayed in the [P].
  - → In a Private Branch Exchange (PBX) environment, press the # key to automatically connect to the outside line.
  - → To correct the entered contents, press the **Back** key.



If you enter the one-touch dial number of the registered destination and press the Select key, you can edit or delete the destination.

- To edit a registered destination, select [EDIT] to edit the registered contents.
- To delete a registered destination, select [DELETE].

#### Registering E-mail addresses

Register destination E-mail addresses.

- Select [UTILITY] [One-Touch Reg] [E-mail], then press the Select key.
- 2 Type in the target one-touch dial number using the Keypad, then press the Select key.
- 3 Enter [Name] (using up to 72 characters), then press the **Select** key.
- When setting the target destination in [Favorites] (frequently used destinations), select [YES], then press the Select key.
- 5 Enter the E-mail address as a destination (using up to 320 characters), then press the **Select** key.



If you enter the one-touch dial number of the registered destination and press the **Select** key, you can edit or delete the destination.

- To edit a registered destination, select [EDIT] to edit the registered contents.
- To delete a registered destination, select [DELETE].

6-17 [Quick Start Guide]

6

[Quick Start Guide] 6-18

# 7 Index

# 7 Index

A	
Address Book How to Register	6-17
Address Registration	
Fax Destination	
Send to E-mail	
C	
Control Panel	
Copy Function	
How to Copy	
Introduction of Copy Function	6-14
E	
Entering Characters	3-11
ErP Auto Power Off	3-6
F	
Fax Function	
How to Send	
Introduction of Receiving FunctionIntroduction of Transmission Function	
Overview	
Preparation	
L	
Loading paper	
Manual Feed Tray	
Tray 1	4-7
M	
Main Screen	3-9
Manual Feed Tray	
N	
Name of each part	
Front side	
Rear side	
Network setting	5-2
0	
Option configuration	3-4
P	
Paper	
Available paper sizes	
Available paper types	
Storing paper Unavailable paper	
Power Save mode	
Power supply	
Preparation	
Fax	5-3
Network setting	
Print (network connection)	
Print (LISB connection)	6-4

Print function	6-2
How to print	6-8
Printer driver	6-2
Initial settings	6-7
Install (network connection)	6-2
Install (USB connection)	6-4
S	
Safety information	1-4
Scan Function	6-9
How to Scan	6-10
Overview	6-9
Screen layout	3-9
Sleep	3-6
Т	
Tray 1	4-7
U	
USB memory	6-15
How to print	
User's Guide	2-3



http://konicaminolta.com