



PRODUCT CONFIGURATION






SPACE REQUIREMENTS AND PLANNING

Main Unit + MX-60ABD (standard drawer plus cabinet) 650-sheet maximum



Main Unit + MX-DE25N (1 additional drawer) 1,200-sheet maximum




Main Unit + MX-DE26N

(2 additional drawers) 1,750-sheet maximum




Main Unit + MX-DE27N

(3 additional drawers) 2,300-sheet maximum




Main Unit + MX-DE28N

(1 additional drawer + 2 split tandem drawers) 3,300-sheet maximum




Main Unit + MX-DE29N


(1 additional drawer – for wheelchair access) 1,200-sheet maximum




Main Unit + MX-DE27N + MX-LC17N (5,300-sheet maximum)



Design and specifications are subject to change without notice. All product dimensions listed are approximate.





Plan ahead to ensure your installation is a great success!

- Firmware: Check the Sharp-PC Service site to make sure
 the machine and accessories have the latest firmware prior to
 installation at the customer site.
- Power Source: Verify the power source at the customer site: MX-M2630: Requires 110-127 V AC @ 60 HZ with a 15 A receptacle outlet and circuit breaker.
- Product Keys: Obtain application codes for any accessories that may require a product key prior to arrival at the customer site.
- **4. Supplies:** Verify that the customer has enough supplies on hand.

MX-561NV Toner
MX-561NV Developer
MX-560DR Drum

MX-560HB Toner Collection Container



Check to see if My Sharp $^{\text{TM}}$ online training is set up for the end-user.

SHARP